

DXM6000/N - 15534-001, TFM6000E/N - 15534-002

REF #	DESCRIPTION	PART #	DXM QTY	TFM QTY		
1	100	ENGINE - B&S 254427-0560	15502-000	1	--	1
2		ENGINE - B&S 254427-0560	64526-003	--	1	2
3						3
4	245	RECEPT. -120/240V L14-30R	97360-000	1	1	4
5	246	RECEPT. - 120V 5-50R	54545-000	1	1	5
6	248	RECEPT. - 120V 5-15R	24749-000	1	1	6
7	249	GFCI RECEPT.- 120V 5-15R	15147-002	1	1	7
8						8
9	251	FRONT PANEL (BARE)	15539-000	1	1	9
10	252	REAR COVER - CONTROL PAN.	15141-000	1	1	10
11						11
12	258	CIRCUIT BREAKER - 15A 1P	64230-001	1	1	12
13	259	CIRCUIT BREAKER - 20A 2P	57030-009	1	1	13
14	261	CIRCUIT BREAKER - 45A 1P	91977-006	1	1	14
15						15
16	502	ROTOR THRU-BOLT (5/16-24)	23197-026	1	1	16
17	511	END BRACKET - ENG END	15008-001	1	1	17
18	512	END BRACKET - BRG END	15015-003	1	1	18
19	514	STATOR ASSEMBLY- M6000/N	15528-000	1	1	19
20						20
21	530	ROTOR ASSY W/BRG & FAN	15522-000	1	1	21
22	532	BEARING	55223-000	1	1	22
23						23
24	545	STATOR THRU-BOLT (1/4-20)	15068-009	4	4	24
25						25
26	560	BRUSH RACK ASSEMBLY	55223-000	1	1	26
27	561	BRUSH PLATE - (BARE)	55224-000	1	1	27
28	562	BRUSH HOLDER	59690-000	2	2	28
29	563	SPACER	23532-000	2	2	29
30	564	BARIER SPACER - CSA	59688-000	2	2	30
31						31
32	565	BRUSH ASSEMBLY W/SPRING	23607-000	2	2	32
33	566	SCREW, BRUSH MTG - #8-32	40746-000	4	4	33
34	569	RECTIFIER - BRIDGE	91452-000	1	1	34
35						35
36	581	END COVER (BARE)	15085-000	1	1	36
37						37
38	601	CRADLE	15178-000	1	1	38
39	602	GENERATOR SUPPORT BKT.	15084-000	1	1	39
40	603	SHOCK MOUNT	64062-000	3	3	40
41						41
42	610	UNIT TOP COVER, FORMED	15146-001	1	1	42
43						43
44	811	REAR TANK SUPPORT PANEL	15132-000	1	1	44
45	815	FUEL VALVE	64091-000	1	1	45
46	817	FUEL TANK-4.5 GALLON	64024-000	1	1	46
47	820	FUEL CAP/GAUGE	62396-003	1	1	47
48						48
49	831	FOAM STRIP- 0.8" X 3ft	64101-000	1	1	49
50						50

DXM6000/N - 15534-001, TFM6000E/N - 15534-002


REF #	DESCRIPTION	PART #	DXM QTY	TFM QTY		
51	851	LP/NG DEMAND REGULATOR	55501-003	--	1	51
52	852	BRACKET, REG. MTG.	64164-000	--	1	52
53	853	LOAD BLOCK (ADJUST.)	63586-000	--	1	53
54	854	HOSE BARB	63587-000	--	1	54
55	855	FUEL ADAPTER (AIR HORN)	64130-000	--	1	55
56						56
57	901	DECAL SET - WARNING	15209-000	1	1	57
58	902	DECAL - DX6000E/WINCO	64214-034	1	--	58
59		DECAL - TF6000E/WINCO	64214-036	--	1	59
60						60
61	906	NAMEPLATE	63966-000	1	1	61
62						62
63	998	OPERATORS MANUAL	60706-106	1	1	63
64		REPAIR PARTS LIST	60701-106	1	1	64

FOLLOWING INFORMATION IS FOR REFERENCE ONLY

000	COMPLETE UNIT ASSEMBLY	15534-001	1	--
	COMPLETE UNIT ASSEMBLY	15534-002	--	1
200	AC PAN. ASSY-DX/TFM6000/N	15540-000	1	1
500	GEN. ASSY. - COMPLETE	15532-001	1	1
535	FAN	15136-002	1	1
537	SLIP-RING	55088-000	1	1
621	BATTERY RACK KIT	15063-004	--	1
800	FUEL SYSTEM- GASOLINE	64094-007	1	1
850	FUEL SYSTEM- TF (LP/NG)	64129-000	--	1

UNIT MODEL SERIES DX/TFM6000/N

AC RESIDUAL VOLTS 7.0 VAC L-L
 G1 WIND. RESISTANCE 0.109 OHMS
 G3 WIND. RESISTANCE 0.180 OHMS
 'Q' WIND. RESISTANCE 0.800 OHMS
 FIELD RESISTANCE 11.5 OHMS
 WINDING SPEC. (SS#) 1544
 ARM. CONNECTION (AC#) 373



WIRING DIAGRAM

MODEL

DXM6000E

TFM6000E

EDF 7-5-91

SD15540

6