

HPM6000H & HPM6000HE			/M	/N	/P	/Q
REF #	DESCRIPTION	QTY	PART #	PART #	PART #	PART #
100	ENGINE	1				
	MANUAL HONDA GX340K1VWE2		15467-000	15467-000	15467-000	15467-000
	ELECTRIC HONDA GX340K1VAW1		15428-000	15428-000	15428-000	15428-000
111	BRACKET, CONSERVER	1	15416-000	15416-000	15416-000	15416-000
112	ELECTRO-MAGNET, CONSERVER	1	15182-000	15182-000	15182-000	15182-000
113	JAM NUT - 5/16-24	3	44894-000	44894-000	44894-000	44894-000
114	COVER, ELECTRO-MAGNET	1	44891-000	44891-000	44891-000	44891-000
115	LEVER, CONSERVER	1	15415-000	15415-000	15415-000	15415-000
116	CONSERVER LEVER CLAMP	1	62309-000	62309-000	62309-000	62309-000
212	RESISTOR, CONS. 150/50W	1	48583-000	48583-000	48583-000	48583-000
213	SWITCH, CONSERVER-SPST	1	64089-000	64089-000	64089-000	64089-000
215	CONSERVER MODULE	1	15110-000	15110-000	15110-000	15110-000
216	TRANSFORMER, CONSERVER	1	54196-000	54196-000	54196-000	54196-000
245	RECEPT. - 240V L6-20R	1	56281-000	56281-000	56281-000	56281-000
246	RECEPT. - 120V 5-50R	1	54545-000	54545-000	54545-000	54545-000
247	RECEPT. - 120V L5-30R	1	56359-000	56359-000	56359-000	56359-000
248	RECEPT. - 120V L5-20R	2	56279-000	56279-000	56279-000	56279-000
249	GFCI RECEPT.- 120V 5-15R	2	15147-002	15147-002	15147-002	15147-002
251	FRONT PANEL (BARE)	1	15399-000	15399-000	15399-000	15399-001
252	REAR COVER - CONTROL PAN.	1	15432-000	15432-000	15432-000	15432-000
258	CIRCUIT BREAKER - 15A 1P	2	64230-000	64230-000	91286-000	91286-000
259	CIRCUIT BREAKER - 20A 2P	1	57030-001	57030-001	57030-001	57030-001
260	CIRCUIT BREAKER - 30A 1P	1	91977-005	91977-005	91977-005	91977-005
261	CIRCUIT BREAKER - 45A 1P	1	91977-006	91977-006	91977-006	91977-006
502	ROTOR THRU-BOLT (5/16-24)	1	23197-026	23197-026	23197-026	23197-026
511	END BRACKET - ENG END	1	15008-001	15008-001	15008-001	15008-000
512	END BRACKET - BRG END	1	USE /N	15533-001	15533-001	15533-002
	STEEL SHIM - BRG BKT		N/A	N/A	N/A	N/A
	TOLERANCE RING - BRG BKT		N/A	N/A	N/A	N/A
545	STATOR THRU-BOLT (1/4-20)	4	15068-009	15068-009	15068-009	15068-009
514	STATOR ASSEMBLY- 6000/M	1	15528-000	15528-000	15528-000	15528-002

HPM6000H & HPM6000HE			/M	/N	/P	/Q
REF #	DESCRIPTION	QTY	PART #	PART #	PART #	PART #
530	ROTOR ASSY W/BRG & FAN	1	15522-000	15522-002	15522-002	15522-002
532	BEARING	1	55223-000	50215-000	50215-000	50215-000
560	BRUSH RACK ASSEMBLY	1	15523-000	15523-000	15523-000	15523-000
561	BRUSH PLATE - (BARE)	1	15524-000	15524-000	15524-000	15524-000
562	BRUSH HOLDER	2	59690-000	59690-000	59690-000	59690-000
563	SPACER	2	23532-000	23532-000	23532-000	23532-000
564	BARRIER SPACER - CSA	2	59688-000	59688-000	59688-000	59688-000
565	BRUSH ASSEMBLY W/SPRING	2	23607-000	23607-000	23607-000	23607-000
566	SCREW, BRUSH MTG - #8-32	4	40746-000	40746-000	40746-000	40746-000
569	RECTIFIER - BRIDGE	1	91452-000	91452-000	91452-000	91452-000
580	END COVER ASSY	1	15089-000	15089-000	15089-000	15089-000
581	END COVER (BARE)	1	15085-000	15085-000	15085-000	15085-000
601	CRADLE	1	15402-000	15402-000	15402-000	15402-000
602	GENERATOR SUPPORT BKT.	1	15084-000	15084-000	15084-000	15084-000
603	SHOCK MOUNT	4	64062-000	64062-000	64062-000	64062-000
610	TOP COVER	1	15431-000	15431-000	15431-000	15431-000
811	REAR TANK SUPPORT PANEL	1	15132-000	15132-000	15132-000	15132-000
812	REAR TANK BAFFLE	1	15144-000	15144-000	15144-000	15144-000
813	TANK SUPPORT PANEL	1	15403-000	15403-000	15403-000	15403-000
814	HOLD DOWN CHANNELS	2	15228-001	15228-001	15228-001	15228-001
815	FUEL VALVE	1	64091-000	64091-000	64091-000	64091-000
816	FUEL FILTER	1	62496-000	62496-000	62496-000	62496-000
817	FUEL TANK-4.5 GALLON	1	64024-000	64024-000	64024-000	64024-000
818	FORMED CHANNEL UNDER TANK	1	64402-001	64402-001	64402-001	64402-001
819	HEAT SHEILD	1	15418-000	15418-000	15418-000	15418-000
820	FUEL CAP/GAUGE	1	62396-003	62396-003	62396-003	62396-003
831	FOAM STRIP- 0.8" X 3ft	1	64101-000	64101-000	64101-000	64101-000
901	DECAL SET - WARNING	1	15209-000	15209-000	15209-000	15209-000
902	DECAL - HP6000H & E	1	64214-042	64214-042	64214-042	64214-042
906	NAMEPLATE	1	63966-000	63966-000	63966-000	63966-000

HPM6000H & HPM6000HE			/M	/N	/P	/Q
REF #	DESCRIPTION	QTY	PART #	PART #	PART #	PART #
	OPERATORS MANUAL	1	60706-113	60706-113	60706-113	60706-113
	REPAIR PARTS LIST	1	60701-205	60701-205	60701-205	60701-205

NOTE: REF 512 HAS BEEN UP GRADED AND NO LONGER REQUIRES A SHIM AND TOLERANCE RING


FOLLOWING INFORMATION IS FOR REFERENCE ONLY

000	COMPLETE UNIT MANUAL		15541-001	15541-003	15541-008	15541-014
	COMPLETE UNIT ELECTRIC		15541-000	15541-002	15541-007	15541-013
110	CONSERVER MOUNT. ASMBLY		15183-000	15183-000	15183-000	15183-000
200	AC PANEL ASSY-HPM6000H		15400-001	15400-001	15400-003	15400-003
500	GEN. ASSY. - COMPLETE		15532-000	15532-002	15532-002	15532-005
535	FAN		15136-002	15136-002	15136-002	15136-002
537	SLIP-RING		55088-000	55088-000	55088-000	55088-000
621	BATTERY RACK KIT		15442-000	15442-000	15442-000	15442-000



G1 WIND. RESISTANCE 0.109 OHMS
 FIELD RESISTANCE 11.5 OHMS
 ARM. CONNECTION AC#373

G3 WIND. RESISTANCE 0.180 OHMS
 WINDING SPEC. SS#1544

WIRING DIAGRAM



DETAIL "A"



MODEL

HPM6000

EDF 7-5-91

SD15401

6