

REF #	DESCRIPTION	QTY	HP4500H/N	HP5000H/N	HP4500H/P	HP5000H/P
			PART #	PART #	PART #	PART #
100	ENGINE - HONDA - GX240	1	15410-000	N/A	15410-000	N/A
	ENGINE - HONDA - GX270	--	N/A	15542-001	N/A	15542-001
112	BRACKET, CONSERVER	1	15414-000	15414-000	15414-000	15414-000
114	LEVER, CONSERVER	1	15413-000	15413-000	15413-000	15413-000
115	CLAMP, CONSERVER LEVER	1	62309-000	62309-000	62309-000	62309-000
294	SWITCH, CONSERVER-SPST	1	64089-000	64089-000	64089-000	64089-000
240	AC PANEL ASSY-HP4500/N	1	15400-000	15400-000	15400-002	15400-002
241	ELECTRO-MAGNET, CONSERVE	1	15182-000	15182-000	15182-000	15182-000
243	RESISTOR, CONS. 150/50W	1	48583-000	48583-000	48583-000	48583-000
244	TRANSFORMER, CONSERVER	1	54196-000	54196-000	54196-000	54196-000
245	RECEPT. - 240V L6-20R	1	56281-000	56281-000	56281-000	56281-000
246	RECEPT. - 120V 5-50R	1	54545-000	54545-000	54545-000	54545-000
247	RECEPT. - 120V L5-30R	1	56359-000	56359-000	56359-000	56359-000
248	RECEPT. - 120V L5-20R	2	56279-000	56279-000	56279-000	56279-000
249	GFCI RECEPT.- 120V 5-15R	2	15147-002	15147-002	15147-002	15147-002
250	FRONT PANEL ONLY	1	15399-000	15399-000	15399-001	15399-001
251	CONSERVER MODULE	1	15110-400	15110-400	15110-400	15110-400
252	REAR PANEL	1	15432-000	15432-000	15432-000	15432-000
258	CIRCUIT BREAKER - 15A 1P	2	64230-000	64230-000	91286-000	91286-000
259	CIRCUIT BREAKER - 20A 2P	1	57030-001	57030-001	57030-001	57030-001
260	CIRCUIT BREAKER - 30A 1P	1	91977-005	91977-005	91977-005	91977-005
261	CIRCUIT BREAKER - 35A 1P	1	91977-008	91977-008	91977-008	91977-008
280	CAPACITOR (40mfd/370V)	2	15051-000	15051-000	15051-000	15051-000
281	CAPACITOR STRAP	1	15088-000	15088-000	15088-000	15088-000
290	END COVER ASSY	1	15114-000	15114-000	15114-000	15114-000
291	END COVER (BARE)	1	15106-000	15106-000	15106-000	15106-000
502	THRU-BOLT	1	23197-009	23197-009	23197-009	23197-009
511	END BRACKET - ENG END	1	15008-001	15008-001	15008-001	15008-001
512	END BRACKET - BRG END	1	15156-001	15156-001	15156-001	15156-001
	TOLERANCE RING	1	15122-000	15122-000	15122-000	15122-000



REF #	DESCRIPTION	QTY	HP4500H/N PART #	HP5000H/N PART #	HP4500H/P PART #	HP5000H/P PART #
514	STATOR ASSEMBLY-	1	15091-005	15091-005	15091-005	15091-005
530	ROTOR ASSY W/BRG & FAN	1	15045-005	15045-005	15045-005	15045-005
532	BEARING	1	55223-000	55223-000	55223-000	55223-000
545	STATOR THUR BOLTS	4	15068-008	15068-008	15068-008	15068-008
601	CRADLE	1	15402-000	15402-000	15402-000	15402-000
602	GENERATOR SUPPORT BKT.	1	15039-000	15039-000	15039-000	15039-000
603	SHOCK MOUNT	3	64062-000	64062-000	64062-000	64062-000
610	UNIT TOP COVER, FORMED	1	15417-000	15417-000	15417-000	15417-000
811	FUEL TANK SUPPORT (REAR)	1	15403-000	15403-000	15403-000	15403-000
815	FUEL FILTER	1	62496-000	62496-000	62496-000	62496-000
817	FUEL TANK- 4.5 GALLON	1	64024-000	64024-000	64024-000	64024-000
820	FUEL CAP/GAUGE	1	62396-003	62396-003	62396-003	62396-003
825	BAFFLE, HEAT SHEILD	1	15418-000	15418-000	15418-000	15418-000
826	BAFFLE, END PANEL	1	15144-000	15144-000	15144-000	15144-000
831	FOAM STRIP- 0.8" X 3ft	1	64101-000	64101-000	64101-000	64101-000
901	DECALS - SAFETY/WARNING	1	15209-000	15209-000	15209-000	15209-000
902	DECAL - HP4500	1	64214-042	64214-042	64214-042	64214-042
998	OPERATORS MANUAL	1	60706-113	60706-113	60706-113	60706-113
	REPAIR PARTS LIST	1	60701-210	60701-210	60701-210	60701-210

FOLLOWING INFORMATION IS FOR REFERENCE ONLY

000	COMPLETE UNIT ASSEMBLY	15409-000	15409-002	15409-004	15409-006
111	CONSERVER PLUG/CORD ASSY	15110-000	15110-000	15110-000	15110-000
500	GEN. ASSY. - COMPLETE	15041-012	15041-012	15041-012	15041-012
535	FAN	15136-001	15136-001	15136-001	15136-001
566	RECTIFIER - STD POLARITY	15047-001	15047-001	15047-001	15047-001
567	RECTIFIER - REV POLARITY	15047-002	15047-002	15047-002	15047-002

AC RESIDUAL VOLTS 7.0 VAC L-L
 ROTOR RESISTANCE 1.0 OHMS
 WINDING SPEC. SS# 1531
 ARM. CONNECTION AC 367

G1 TO N 0.18 OHMS
 G3 TO N 0.36 OHMS
 "Q" WINDINGS 0.55 OHMS



WIRING DIAGRAM

MODEL	HP4500H		
EDF	11-8-90	SD154000	6