

WIRING DIAGRAM 63007
 GEN UNASSEMBLED 62002-2
 COMPLETE UNIT 63005


 REPAIR
 PARTS LIST
 #757

SIZE 4800 WATTS
 DRIVE DIRECT
 TYPE TWO POLE
 MODEL K4800/B

REF#	DESCRIPTION	PART#	QTY	REF#	DESCRIPTION	PART#	QTY
110	BAT CABLE ASSY	62499	1	442	POLE SHOE	23207	
111	OIL DRAIN TUBE	62498	1	443	POLE SHOE RETAIN	23208	
201	CONTOL BOX COVER	62057-2	1	444	FIELD SHELL	55417	
212	BACK PANEL	62053	1	445	STUD 5/16-18X2-3/8	23451	4
214	RESISTOR	41984	4	446	D.C. BRUSH	41393	2
218	START STOP SW	62393	1	447	AC BRUSH	55536	10
230	START SOLENOID	24061	1	460A	BRUSH RACK ASSY	61997	1
233A	L.E.D. ASSY D.C.	62489	1	460B	BRUSH RACK ASSY	61997-1	1
233B	L.E.D. ASSY A.C.	62490	1	461	BR HLD MTG PLT	41745	1
234	BAT CONNECTOR	56148	1	462	A.C. BRUSH HOLDER	59690	10
247	RECP NEMA 5-50R	54545	1	465	BR HLD MTG PLT	61093	1
249	FRONT PANEL BARE	62054-3	1	463	A.C. CAPACITOR	41221	2
250	HEAT SINK & RECT	54776	1	466	D.C. CAPACITOR	41180	1
257	RECP NEMA 6-50R	57325	1	491	END COVER	55438-10	1
258	CIR BRK 15A	91598	2	601	CRADLE WRAP AROUND	62035	
259	RECPT NEMA 5-15R	24749	2				
289	CIR BRK 10A-12V	91940	1	604A	SHOCK MOUNT	20191	4
310	D.C. AMMETER	62394	1	604B	SHOCK MOUNT	23623	4
				614	FUEL TANK TRAY	62015	1
401	FAN	55101	1				
402	THRUBOLT	23197-7	1	817	FUEL TANK	61934	1
411	END BRACKET	62504	1	818	PRIMER	62391	1
				819	FUEL PUMP	81332-2	1
431	ARMATURE	61956-1	1	820	CAP/GAUGE	62396	1
432	BEARING	55223	1		Cap Only	15482	
441A	FIELD COIL	55422	1				
441B	FIELD COIL	55422-1	1				



225 South Cordova Avenue
 Le Center, MN 56057 • (612) 357-6821



K5000/c

K4800/B

C3007